

EUROCOMPONENTS

Internal clutch mounting instructions

Assembly should be performed by an authorized motorcycle technician



Mounting instructions

- 1) cut 4 inches off handlebars tubing on left side, or whatever needed to accommodate your grip. This section is replaced by the internal clutch assembly itself. The smaller part of the unit is the one which will slip inside the bars.
- 2) pass cable through the hole of cable sleeve (B).
- 3) fix cable with side set screw inside piston (D).
- 4) fix cable sleeve (B) inside unit (C) using the set screw.
- 5) locate the button head screw (A) on the assembly (C).
- 6) drill and tap bar for screw (A) or weld it to the handlebars (we strongly suggest to weld this screw or to use red loctite, since this will hold the internal clutch on the handlebars).

Notes

Any type of Ø 1" grips can fit over our internal clutch assembly.
The easiest way is to use a left hand grip and tighten it using set screws.
Be careful not to overtighten set screws, since the mechanism could jam.
It must be used in conjunction with our master cylinder with lever (p/n K0351-C/P/B).
Remember to lube the inside of the mechanism with waterproof grease.

