

# EUROCOMPONENTS

## *Internal throttle mounting instructions*

Assembly should be performed by an authorized motorcycle technician



### **Mounting instructions**

- 1) cut 4 inches off handlebars tubing on throttle side, or whatever needed to accommodate your grip. This section is replaced by the internal throttle assembly itself. The smaller part of the unit is the one which will slip inside the bars.
- 2) pass cable through the hole of cable sleeve (B).
- 3) fix cable with side set screw inside piston (D).
- 4) fix cable sleeve (B) inside throttle unit (C) using the set screw.
- 5) locate the button head screw (A) on the assembly (C).
- 6) drill and tap bar for screw (A) or weld it to the handlebars (we strongly suggest to weld this screw or to use red loctite, since this will hold the internal throttle on the handlebars).

### **Notes**

Any type of  $\varnothing$  1" grips can fit over our internal throttle assembly.  
The easiest way is to use a left hand grip and tighten it using set screws.  
Regular throttle grips can also fit, but throttle part has to be cut off.  
Be careful not to overtighten set screws, since the mechanism could jam.  
For best results we suggest to use a Barnett throttle cable.  
Remember to lube the inside of the mechanism with waterproof grease.

