

# EUROCOMPONENTS

## *Mounting instructions for weld-on pop-up gas caps*

Assembly should be performed by an authorized motorcycle technician

---

- 1) weld bung in steel tank
- 2) check cap clearance before painting or chroming
- 3) do not overfill your gas tank, always leave at least 3/4" of an inch air gap

